



Inclement Weather

- Button for Inclement Weather is simply a switch.
- Press the button labeled 'Inclement Weather' and it will light up.
- To turn off, press the button again.

Note: This can also be performed remotely by dialing into an IVR, entering a passcode and selecting the appropriate option.

For additional features with your plan, check with your administrator or contact Hiscall, Inc.

To turn Inclement Weather off, they simply press the button again. This can also be performed

**Need More
Assistance?
Contact Hiscall:**

HISCALL, INC.



www.Hiscall.com
866-740-7771